

## LCP HANDALL® HYBRID INSTALLATION PROCEDURE


*If you have any problems, don't hesitate to call us.*

### HOGUE INC.

P.O. BOX 91360  
HENDERSON, NV 89009  
1-800-438-4747

**Hogueinc.com**

1. Before starting to work, make sure the firearm is unloaded and made safe with the magazine removed.





2. Remove the "Hammer Spring Seat" by depressing the tab through the hole at the rear of the frame while pulling the "Hammer Spring Seat" from the pistol.


3. Using a suitable punch, remove the "Frame Insert Pin."



4. Hook the HandAll onto the front bottom corner of the pistol. Rotate onto frame and push up until the integral "Hammer Spring Seat" is firmly seated into the bottom of the pistol where the original "Hammer Spring Seat" was removed.



5. While lining up the holes on your new LCP HandAll hybrid grip with the hole on the frame of your firearm, carefully insert the supplied "Frame Insert Pin" narrow end first, from either side of the pistol. Make sure it is flush with the grip on both sides of the firearm. This may require tapping the pin into place with a suitable soft face hammer.



## To Remove the HandAll

1. Utilizing a suitable punch, remove the "Frame Insert Pin." Simply pull and rotate the grip off of the frame.



## IMPORTANT!

Check all functions of your firearm after grips are installed. Test-fire your firearm. This is especially important if weapon is to be used for law enforcement duty.